





Ersatzteilliste

Pos.	Stück	Benennung	Bestell-Nr.	Einsteckende
1	1	Buchse	.52/7504	S 22x82,5
2	1	Zylinder	.52/7805	
3	1	Kolben	.52/7806	
4	1	Rohrschieber	.52/7877	
5	1	Steuergehäuse	.52/7807	
6	1	Steuergehäusering	.52/7876	
7	1	Deckel	.52/7857	
8	1	Stift	304/3635	
9	1	Puffer	307/2563	
10	1	Ring	307/2516	
11	1	O-Ring	307/2477	
12	1	Spannflansch	.52/2503	
13	4	Schraube	308/060450	
14	1	Griff kpl.	.52/2555	
15	2	Griffstück	.52/2557	
16	2	Griffschutz	307/2568	
17	1	Deckel	307/2574	
18	1	Drücker	.52/2558	
19	2	Spannstift	304/3532	
20	1	Spannstift	304/3650	
21	1	Ventil	.52/7532	
22	1	Kugel	307/2088	
23	1	Nippel	306/0228	
24	1	Sicherungsring	304/7165	
25	2	Feder	304/7540	
26	1	Feder	304/7541	
27	1	Haltekappe kpl.	.52/2507	
28	1	Haltehebel	.52/2846	
29	1	Druckstift	.52/8115	
30	1	Schraube	308/100105	
31	1	Mutter	308/110020	
32	1	Spannstift	304/3654	
33	1	Spannstift	304/3653	
34	1	Feder	304/7501	
35	1	Schalldämpfer	307/2569	
36	1	Spannband	.52/2509	
37	1	Spannschloß	306/0489	
38	1	Umlenkung	307/2573	