
9 Exploded view FK 2015 R.10

FK 2015 R.10 · 052-642110 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
15	2	Impact ring	307-2043
16	1	Complete handle	052-2500
17	1	Trigger	307-2556
18	1	Spring pin	304-3532
19	1	Valve	052-7532
20	1	Ball	307-2088
21	1	Plug	052-2510
22	1	Spring	304-7535
23	1	Plug	318-0206 21 00
24	1	Nipple	306-0228
25	1	Sealing ring	313-531775
14	1	Complete screw cap	052-7878


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.11

FK 2015 R.11 · 052-642111 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
14	1	Complete handle	052-2500
15	1	Trigger	307-2556
16	1	Pin	304-3532
17	1	Valve	052-7532
18	1	Ball	307-2088
19	1	Plug	052-2510
20	1	Spring	304-7535
21	1	Plug	318-0206 21 00
22	1	Nipple	306-0228
23	1	Sealing ring	313-531775
25	2	Impact ring	307-2043
26	1	Silencer	307-2570
27	1	Clamping band	052-2509
28	1	Clamping fastener	306-0489
29	1	Deflector	307-2573
24	1	Complete screw cap	052-7878


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.20

FK 2015 R.20 · 052-642120 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
14	1	Complete handle	052-2505
16	1	Trigger	307-2571
17	1	Spring pin	304-3532
18	1	Valve	052-7532
19	1	Ball	307-2088
20	2	Handle guard	307-2568
21	1	Slotted spring pin	304-3544
22	1	Spring	304-7046
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	1	Retaining lever	052-2846
26	1	Pin	052-8115
27	1	Screw	308-100105
28	1	Nut	308-110020
29	1	Spring pin	304-3654
30	1	Spring pin	304-3653
31	1	Spring	304-7501
15	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.21

FK 2015 R.21 · 052-642121 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
15	1	Retaining lever	052-2846
16	1	Pin	052-8115
17	1	Screw	308-100105
18	1	Nut	308-110020
19	1	Spring pin	304-3654
20	1	Spring pin	304-3653
21	1	Spring	304-7501
22	1	Complete handle	052-2505
23	1	Trigger	307-2571
24	1	Spring pin	304-3532
25	1	Valve	052-7532
26	1	Ball	307-2088
27	2	Handle guard	307-2568
28	1	Slotted spring pin	304-3544
29	1	Spring	304-7046
30	1	Nipple	306-0228
31	1	Sealing ring	313-531775
32	1	Silencer	307-2570
33	1	Clamping fastener	306-0489
34	1	Clamping band	052-2509
35	1	Deflector	307-2573
14	1	Complete retaining cap	052-2507

NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.30

FK 2015 R.30 · 052-642130 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
15	1	Complete handle	052-2500
16	1	Trigger	307-2556
17	1	Spring pin	304-3532
18	1	Valve	052-7532
19	1	Ball	307-2088
20	1	Plug	052-2510
21	1	Spring	304-7535
22	1	Plug	318-0206 21 00
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	1	Retaining lever	052-2846
26	1	Pin	052-8115
27	1	Screw	308-100105
28	1	Nut	308-110020
29	1	Spring pin	304-3654
30	1	Spring pin	304-3653
31	1	Compression spring	304-7501
14	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.31

FK 2015 R.31 · 052-642131 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
15	1	Complete handle	052-2500
16	1	Trigger	307-2556
17	1	Spring pin	304-3532
18	1	Valve	052-7532
19	1	Ball	307-2088
20	1	Plug	052-2510
21	1	Spring	304-7535
22	1	Plug	318-0206 21 00
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	1	Silencer	307-2570
26	1	Clamping band	052-2509
27	1	Clamping fastener	306-0489
28	1	Deflector	307-2573
29	1	Retaining lever	052-2846
30	1	Pin	052-8115
31	1	Screw	308-100105
32	1	Nut	308-110020
33	1	Spring pin	304-3654
34	1	Spring pin	304-3653
35	1	Compression spring	304-7501
14	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.40

FK 2015 R.40 · 052-642140 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
15	1	Complete handle	052-2500
16	1	Trigger	307-2556
17	1	Spring pin	304-3532
18	1	Valve	052-7532
19	1	Ball	307-2088
20	1	Plug	052-2510
21	1	Spring	304-7535
22	1	Plug	318-0206 21 00
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	1	Retaining lever	052-2846
26	1	Pin	052-8115
27	1	Screw	308-100105
28	1	Nut	308-110020
29	1	Spring pin	304-3654
30	1	Spring pin	304-3653
31	1	Compression spring	304-7501
14	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.41

FK 2015 R.41 · 052-642141 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
15	1	Complete handle	052-2500
16	1	Trigger	307-2556
17	1	Spring pin	304-3532
18	1	Valve	052-7532
19	1	Ball	307-2088
20	1	Plug	052-2510
21	1	Spring	304-7535
22	1	Plug	318-0206 21 00
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	1	Silencer	307-2570
26	1	Clamping band	052-2509
27	1	Clamping fastener	306-0489
28	1	Deflector	307-2573
29	1	Retaining lever	052-2846
30	1	Pin	052-8115
31	1	Screw	308-100105
32	1	Nut	308-110020
33	1	Spring pin	304-3654
34	1	Spring pin	304-3653
35	1	Compression spring	304-7501
14	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.50

FK 2015 R.50 · 052-642150 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
15	2	Impact ring	307-2043
16	1	Complete handle	052-2505
17	1	Trigger	307-2571
18	1	Spring pin	304-3532
19	1	Valve	052-7532
20	1	Ball	307-2088
21	2	Handle guard	307-2568
22	1	Slotted spring pin	304-3544
23	1	Spring	304-7046
24	1	Nipple	306-0228
25	1	Sealing ring	313-531775
14	1	Complete screw cap	052-7878


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.60

FK 2015 R.60 · 052-642160 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
14	1	Complete handle	052-2505
16	1	Trigger	307-2571
17	1	Spring pin	304-3532
18	1	Valve	052-7532
19	1	Ball	307-2088
20	2	Handle guard	307-2568
21	1	Slotted spring pin	304-3544
22	1	Spring	304-7046
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	1	Retaining lever	052-2846
26	1	Pin	052-8115
27	1	Screw	308-100105
28	1	Nut	308-110020
29	1	Spring pin	304-3654
30	1	Spring pin	304-3653
31	1	Spring	304-7501
15	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.61

FK 2015 R.61 · 052-642161 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
15	1	Retaining lever	052-2846
16	1	Pin	052-8115
17	1	Screw	308-100105
18	1	Nut	308-110020
19	1	Spring pin	304-3654
20	1	Spring pin	304-3653
21	1	Spring	304-7501
22	1	Complete handle	052-2505
23	1	Trigger	307-2571
24	1	Spring pin	304-3532
25	1	Valve	052-7532
26	1	Ball	307-2088
27	2	Handle guard	307-2568
28	1	Slotted spring pin	304-3544
29	1	Spring	304-7046
30	1	Nipple	306-0228
31	1	Sealing ring	313-531775
32	1	Silencer	307-2570
33	1	Clamping fastener	306-0489
34	1	Clamping band	052-2509
35	1	Deflector	307-2573
14	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.64

FK 2015 R.64 · 052-642164 · R 25x75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7872
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
14	1	Complete handle	052-2555
15	2	Grip section	052-2557
16	2	Handle guard	307-2568
17	1	Cover	307-2574
18	1	Trigger	052-2558
19	2	Pin	304-3444
20	1	Spring pin	304-3650
21	1	Valve	052-7532
22	1	Ball	307-2088
23	1	Nipple	306-0228
24	1	Sealing ring	313-531775
25	2	Spring	304-7540
26	1	Spring	304-7541
28	1	Retaining lever	052-2846
29	1	Pin	052-8115
30	1	Screw	308-100105
31	1	Nut	308-110020
32	1	Spring pin	304-3654
33	1	Spring pin	304-3653
34	1	Spring	304-7501
35	1	Silencer	307-2570
36	1	Clamping band	052-2509
37	1	Clamping fastener	306-0489
38	1	Deflector	307-2573
27	1	Complete retaining cap	052-2507


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.70

FK 2015 R.70 · 052-642170 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
15	2	Impact ring	307-2043
16	1	Complete handle	052-2500
17	1	Trigger	307-2556
18	1	Spring pin	304-3532
19	1	Valve	052-7532
20	1	Ball	307-2088
21	1	Plug	052-2510
22	1	Spring	304-7535
23	1	Plug	318-0206 21 00
24	1	Nipple	306-0228
25	1	Sealing ring	313-531775
14	1	Complete screw cap	052-7880


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.71

FK 2015 R.71 · 052-642171 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2504
13	4	Screw	308-060450
14	1	Complete handle	052-2500
15	1	Trigger	307-2556
16	1	Pin	304-3532
17	1	Valve	052-7532
18	1	Ball	307-2088
19	1	Plug	052-2510
20	1	Spring	304-7535
21	1	Plug	318-0206 21 00
22	1	Nipple	306-0228
23	1	Sealing ring	313-531775
25	2	Impact ring	307-2043
26	1	Silencer	307-2570
27	1	Clamping band	052-2509
28	1	Clamping fastener	306-0489
29	1	Deflector	307-2573
24	1	Complete screw cap	052-7880


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.80

FK 2015 R.80 · 052-642180 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
15	2	Impact ring	307-2043
16	1	Complete handle	052-2505
17	1	Trigger	307-2571
18	1	Spring pin	304-3532
19	1	Valve	052-7532
20	1	Ball	307-2088
21	2	Handle guard	307-2568
22	1	Slotted spring pin	304-3544
23	1	Spring	304-7046
24	1	Nipple	306-0228
25	1	Sealing ring	313-531775
14	1	Complete screw cap	052-7878


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2015 R.81

FK 2015 R.81 · 052-642181 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7504
2	1	Cylinder	052-7854
3	1	Piston	052-7855
4	1	Valve sleeve	052-7877
5	1	Valve housing	052-7856
6	1	Control housing ring	052-7876
7	1	Valve housing cover	052-7857
8	1	Pin	304-3635
9	1	Buffer	307-2563
10	1	Ring	307-2516
11	1	O-ring	307-2477
12	1	Clamping flange	052-2503
13	4	Screw	308-060450
15	2	Impact ring	307-2043
16	1	Complete handle	052-2505
17	1	Trigger	307-2571
18	1	Spring pin	304-3532
19	1	Valve	052-7532
20	1	Ball	307-2088
21	2	Handle guard	307-2568
22	1	Slotted spring pin	304-3544
23	1	Spring	304-7046
24	1	Nipple	306-0228
25	1	Sealing ring	313-531775
26	1	Silencer	307-2570
27	1	Clamping fastener	306-0489
28	1	Clamping band	052-2509
29	1	Deflector	307-2573
14	1	Complete screw cap	052-7878

NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control housing cover can damage the hammer. Always replace buffer 307-2563 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.