
9 Exploded view FK 2020 R.20

FK 2020 R.20 · 052-642220 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-2849
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	1	Retaining lever	052-2846
24	1	Spring pin	304-3654
25	1	Spring pin	304-3653
26	1	Pin	052-8115
27	1	Spring	304-7501
28	1	Screw	308-100105
29	1	Nut	308-110020
22	1	Complete retaining cap	052-2520


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.21

FK 2020 R.21 · 052-642221 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-2849
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	1	Retaining lever	052-2846
24	1	Spring pin	304-3654
25	1	Spring pin	304-3653
26	1	Pin	052-8115
27	1	Spring	304-7501
28	1	Screw	308-100105
29	1	Nut	308-110020
30	1	Clamping band	052-2529
31	1	Clamping fastener	306-0489
32	1	Deflector	307-2573
33	1	Silencer	307-2572
22	1	Complete retaining cap	052-2520


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.24

FK 2020 R.24 · 052-642224 · S 22 x 82,5. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-2849
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2565
13	2	Grip section	052-2557
14	2	Handle guard	307-2568
15	1	Cover	307-2574
16	1	Trigger	052-2558
17	2	Spring pin	304-3532
18	1	Spring pin	304-3650
19	1	Valve	052-7532
20	1	Ball	307-2088
21	1	Nipple	306-0228
22	1	Sealing ring	313-531775
23	2	Spring	304-7540
24	1	Spring	304-7541
26	1	Retaining lever	052-2846
27	1	Spring pin	304-3654
28	1	Spring pin	304-3653
29	1	Pin	052-8115
30	1	Spring	304-7501
31	1	Screw	308-100105
32	1	Nut	308-110020
33	1	Silencer	307-2572
34	1	Clamping band	052-2529
35	1	Clamping fastener	306-0489
36	1	Deflector	307-2573
25	1	Complete retaining cap	052-2520


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.50

FK 2020 R.50 · 052-642250 · R 25 x 75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7762
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	2	Impact ring	307-2043
22	1	Complete screw cap	052-1925


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.51

FK 2020 R.51 · 052-642251 · R 25 x 75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7762
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	2	Impact ring	307-2043
24	1	Silencer	307-2572
25	1	Clamping band	052-2529
26	1	Clamping fastener	306-0489
27	1	Deflector	307-2573
22	1	Complete screw cap	052-1925


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.60

FK 2020 R.60 · 052-642260 · R 25 x 75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7762
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	1	Retaining lever	052-2846
24	1	Spring pin	304-3654
25	1	Spring pin	304-3653
26	1	Pin	052-8115
27	1	Spring	304-7501
28	1	Screw	308-100105
29	1	Nut	308-110020
22	1	Complete retaining cap	052-2520


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.61

FK 2020 R.61 · 052-642261 · R 25 x 75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7762
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	1	Retaining lever	052-2846
24	1	Spring pin	304-3654
25	1	Spring pin	304-3653
26	1	Pin	052-8115
27	1	Spring	304-7501
28	1	Screw	308-100105
29	1	Nut	308-110020
30	1	Clamping band	052-2529
31	1	Clamping fastener	306-0489
32	1	Deflector	307-2573
33	1	Silencer	307-2572
22	1	Complete retaining cap	052-2520


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.64

FK 2020 R.64 · 052-642264 · R 25 x 75. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7762
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2565
13	2	Grip section	052-2557
14	2	Handle guard	307-2568
15	1	Cover	307-2574
16	1	Trigger	052-2558
17	2	Spring pin	304-3532
18	1	Spring pin	304-3650
19	1	Valve	052-7532
20	1	Ball	307-2088
21	1	Nipple	306-0228
22	1	Sealing ring	313-531775
23	2	Spring	304-7540
24	1	Spring	304-7541
26	1	Retaining lever	052-2846
27	1	Spring pin	304-3654
28	1	Spring pin	304-3653
29	1	Pin	052-8115
30	1	Spring	304-7501
31	1	Screw	308-100105
32	1	Nut	308-110020
33	1	Silencer	307-2572
34	1	Clamping band	052-2529
35	1	Clamping fastener	306-0489
36	1	Deflector	307-2573
25	1	Complete retaining cap	052-2520


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.90

FK 2020 R.90 · 052-642290 · S 25 x 108. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7486
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Sealing ring	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	1	Retaining lever	052-2846
24	1	Spring pin	304-3654
25	1	Spring pin	304-3653
26	1	Pin	052-8115
27	1	Spring	304-7501
28	1	Screw	308-100105
29	1	Nut	308-110020
22	1	Complete retaining cap	052-2521


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.91

FK 2020 R.91 · 052-642291 · S 25 x 108. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7486
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2525
13	1	Trigger	307-2571
14	1	Spring pin	304-3532
15	1	Valve	052-7532
16	1	Ball	307-2088
17	1	Seal	313-531775
18	1	Spring	304-7046
19	1	Nipple	306-0228
20	1	Slotted spring pin	304-3544
21	2	Handle guard	307-2568
23	1	Retaining lever	052-2846
24	1	Spring pin	304-3654
25	1	Spring pin	304-3653
26	1	Pin	052-8115
27	1	Spring	304-7501
28	1	Screw	308-100105
29	1	Nut	308-110020
30	1	Clamping band	052-2529
31	1	Clamping fastener	306-0489
32	1	Deflector	307-2573
33	1	Silencer	307-2572
22	1	Complete retaining cap	052-2521


NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.

9 Exploded view FK 2020 R.94

FK 2020 R.94 · 052-642294 · S 25 x 108. Blue links open spare parts in the shop.



10 Spare parts

Item	Qty.	Description	Part number
1	1	Bushing	052-7486
2	1	Cylinder	052-2700
3	1	Piston	052-1902
4	1	Valve sleeve	052-1904
5	1	Valve housing	052-2703
6	1	Complete buffer	052-2707
7	1	Pin	304-3632
8	1	Ring	307-2527
9	1	O-ring	307-2478
10	1	Clamping flange	052-2514
11	4	Screw	308-060450
12	1	Complete handle	052-2565
13	2	Grip section	052-2557
14	2	Handle guard	307-2568
15	1	Cover	307-2574
16	1	Trigger	052-2558
17	2	Spring pin	304-3532
18	1	Spring pin	304-3650
19	1	Valve	052-7532
20	1	Ball	307-2088
21	1	Nipple	306-0228
22	1	Sealing ring	313-531775
23	2	Spring	304-7540
24	1	Spring	304-7541
26	1	Retaining lever	052-2846
27	1	Spring pin	304-3654
28	1	Spring pin	304-3653
29	1	Pin	052-8115
30	1	Spring	304-7501
31	1	Screw	308-100105
32	1	Nut	308-110020
33	1	Silencer	307-2572
34	1	Clamping band	052-2529
35	1	Clamping fastener	306-0489
36	1	Deflector	307-2573
25	1	Complete retaining cap	052-2521

NOTICE – Damage to the cylinder
Incorrect removal or replacement of the chisel bushing can damage the cylinder. Have chisel bushings replaced exclusively by F+K Service. Do not remove or replace them yourself.

NOTICE – Damage to the hammer
Reusing the old buffer when replacing the control mechanism can damage the hammer. Always replace buffer 052-2707 during this work.

Variants and spare-parts orders
Order spare parts using the article number of this version.