


FK 4



Ersatzteilliste

Pos.	Stück	Benennung	Bestell-Nr.	Einsteckende
1	1	Buchse	.52/0501	RS 17,5
			.52/0502	R 17,5x60
			.52/0503	RS 20
			.52/0504	R 20x60
2	1	Zylinder	.52/0500	
3	1	Kolben	.52/0549	
4	1	Zylinderdeckel	.52/0274	
5	1	Rohrschieber	.52/0238	
6	1	Puffer	307/2504	
7	1	Konischer Ring	307/2115	
8	1	Griff kpl.	.52/0505	
9	1	Zylinderstift	304/3442	
10	1	Drücker	.52/0057	
11	1	Ventil	.52/0117	
12	1	Kugel	307/1987	
13	1	Druckfeder	304/7018	
14	1	Nippel	306/0223	
15	1	Stopfen	306/0202	
16	1	Stift	304/3630	
17	1	Ring	307/2545	
18	1	Klemmutter	.52/05071	
19	1	Schalldämpfer	307/2537	
20	1	Schraubkappe	.52/8403	
21	2	Prellring	307/2114	
22	1	Stift	304/3628	
23	1	O-Ring	307/2167	