


FK 5 W



Spare Parts List

Pos.	QTY	Item	Part no.	Spigot
1	1	Bushing	.52/0501	RS 17,5
			.52/0502	R 17,5x60
			.52/0503	RS 20
			.52/0504	R 20x60
2	1	Cylinder	.52/0510	
3	1	Piston	.52/0559	
4	1	Cylinder cover	.52/0274	
5	1	Hollow spool valve	.52/0238	
6	1	Buffer	307/2504	
7	1	Conical ring	307/2115	
8	1	Handle complete	.52/0505	
9	1	Straight pin	304/3442	
10	1	Trigger	.52/0057	
11	1	Valve	.52/0117	
12	1	Ball	307/1987	
13	1	Spring	304/7018	
14	1	Fitting	306/0223	
15	1	Stuff	306/0202	
16	1	Pin	304/3630	
17	1	Ring	307/2545	
18	1	Clamping nut	.52/0517	
19	1	Exhaust clip	304/7254	
20	1	Screw cap	.52/8403	
21	2	Buffer ring	307/2114	
22	1	Pin	304/3628	
23	1	O-ring	307/2167	