


FK 711



Ersatzteilliste

Pos.	Stück	Benennung	Bestell-Nr.			
			<i>Einsteckende</i>			
			R 10,3x36	R 12,7x50	R 12,7x55	
1	1	Buchse	.52/7233	.52/0043	.52/0083	
2	1	Zylinder	.52/0077	.52/0042		
3	1	Kolben	.52/0078			
4	1	Unterdeckel	.52/0051			
5	1	Steuerplatte	307/2337			
6	1	Oberdeckel	.52/0050			
7	1	Stift	304/5646			
8	1	Puffer	307/2338			
9	1	Griff, kpl.	.52/0151			
10	1	Klemmutter	.52/0058			
11	1	Schalldämpfer	307/2540			
12	1	O-Ring	307/2439			
13	1	Ventil, kpl.	.52/0142			
14	1	Sieb	304/5069			
15	1	Drücker	307/2339			
16	1	Druckfeder	304/7015			
17	1	Stopfen	306/0200			
18	1	Ventilbuchse	.52/0141			Nach Einbau auf Passung 5H7 aufreiben!
+	1	Schlauch ohne Kupplung	.52/0160			
	1	Schlauch mit Kupplung	.52/0160			
			306/0805			