


## FK 4.3



### Ersatzteilliste

Pos.	Stück	Benennung	Bestell-Nr.	Einsteckende
1	1	Buchse	.52/0501	RS 17,5
			.52/0502	R 17,5x60
			.52/0503	RS 20
			.52/0504	R 20x60
2	1	Zylinder	.52/0571	
3	1	Kolben	.52/0549	
4	1	Zylinderdeckel	.52/0274	
5	1	Rohrschieber	.52/0238	
6	1	Puffer	307/2504	
7	1	Griff kpl.	.52/0505	
8	1	Zylinderstift	304/3630	
9	1	Ring	307/2545	
10	1	Klemmutter	.52/05071	
11	1	Schalldämpfer	.52/0567	
12	1	Federkappe	304/7801	
13	1	Drücker	.52/0057	
14	1	Stift	304/3442	
15	1	Ventil	.52/0117	
16	1	Kugel	307/1987	
17	1	Feder	304/7018	
18	1	Stopfen	306/0202	
19	1	Nippel	306/0223	
20	1	Stift	304/3628	
21	1	O-Ring	307/2167	